



# Assembling the rain hat




The rain hat has four adjustable cords and a metal ring that can be taken apart. Start by putting the metal ring together and then feed it into the channel at the bottom of the hat, see picture 1. When the whole ring is in place – see picture 2 – press it together as in picture 3.



At the top, on the reverse side of the rain hat, there is a strip of Velcro, see picture 4. Attach the Velcro around the hanging loop located at the top of the Nordic tipi, see picture 5.

# ... continuation



The four adjustable cords are attached with toggles to four of the buttonhole bands, where the storm cords and the ventilator cap are attached, see picture 6. Keep the rain hat's cords loose so as to facilitate the pitching of the Nordic tipi. Once the tent is erected, the cords can be adjusted using the buckle, see picture 7.



When the rain hat is mounted, it is possible to maintain a pleasant indoor climate on warm, rainy days since the ventilator cap can be fully open without rain coming in.

NB! The rain hat must be removed when a stove/fire is burning inside the tent.